
connecting back-to-back erential inputs. This techise level and can be used increase in input current. ints look like short circuits of signal sources provide ver levels that are easily

ifferential inputs to a lowg normal circuit operation rotection involves adding ach signal path prior to the use the input noise level to i).

lexers or resistors, should the formation of thermograde the input signal.



tion for gains 2 to 10,000.

## TIONS

of precision amplifiers in a attention to external influand changes in the nominal set voltage. A PSR of 80dB / on the supply, not an  $10\mu V$  input offset change. In in choosing a power unit wel, good line and load stability.

## **APPLICATIONS INFORMATION**




Figure 7. High-compliance bipolar current source with 13-bit linearity.




Figure 8. 13-bit linear 4-20mA transmitter constructed by adding a voltage reference. Thermocouple signals can be accepted without preamplification.